

구성품

한국어

※2열 헤드, 각도형 헤드, 레귤러 헤드 칫솔모 등 별매품 추가 구매 가능



본체

여행용 케이스

칫솔 헤드 보관 케이스

사용자 매뉴얼

1

제품구조

한국어



칫솔 헤드

전원/작동 버튼

강도 표시 LED

충전 표시 LED

무선 충전 거치대


2

제품기능

한국어



칫솔 헤드 교체



- 왼쪽 그림과 같은 방법으로 칫솔 헤드를 장착할 수 있습니다. (칫솔 헤드가 임쪽으로 향하게 장착하여 주십시오. 방향이 맞지 않는 상태로 무리하게 장착하면 제품이 손상될 수 있습니다.)
- 본 제품의 칫솔 헤드는 패키지에 동봉되어 있습니다.
- 칫솔 헤드는 3개월마다 교체하여 주십시오. 3개월이 지나지 않더라도, 칫솔모의 형태가 변형되었다면 칫솔 헤드를 교체하십시오. (칫솔 헤드는 별매품으로 구매 할 수 있습니다.)
- 다른 제품의 칫솔 헤드는 호환이 되지 않습니다. 타제품의 무리한 칫솔 헤드 장착은 고장의 원인이 될 수 있습니다.
- 칫솔 헤드 결합 후 본체와 칫솔 헤드 사이에 1mm 정도 틈이 있습니다. 이는 칫솔의 소음을 위한 것으로 정상입니다. (틈을 없애려고 과도하게 누를 시 제품 고장의 원인이 될 수 있습니다.)


3

사용방법

한국어

- 1. 양치질 준비**
칫솔모에 치약을 적당량 도포 합니다.
본 제품은 치약 텀 방지 기능이 탑재되어 있어 3초동안 점차 세기가 강해집니다.
3초 내에 칫솔질을 시작하십시오.
- 2. 전원ON, 모드조절**
전원버튼을 짧게 눌러 전원을 켭니다.
전원이 켜진 상태에서 다시 전원버튼을 짧게 눌러 모드를 변경하며 사용자에게 맞는 모드로 양치질을 시작하십시오
- 3. 사용, 전원 OFF**
양치질은 2분 정도 하는 것을 권장 드립니다. 2분간 양치질을 하면 자동으로 전원이 꺼집니다. 양치질 도중 전원을 끄고 싶다면 전원버튼을 1초 이상 길게 누르십시오.
- 4. 세척 및 건조**
사용 후 칫솔모를 흐르는 물에 잘 씻어주고, 자연 건조해주십시오. 사용 후에는 건조하고 선선한 곳에 보관하여 주십시오.

스마트 2분 타이머 · 30초 구간 알림



- 본 제품에는 양치질 시간을 가이드 하는 타이머 기능이 탑재되어 있습니다.
- 양치질은 2분간 진행되며 2분이 지나면 자동으로 전원이 꺼집니다.
- 구강을 4구역으로 나누어 30초씩 골고루 양치질을 할 수 있도록 30초가 지나면 잠시 정지하여 신호를 줍니다. 진동이 울릴 때마다 구역을 변경하여 골고루 양치질 하십시오.

4

IPX8




75 % recycled paper
75 % recycled paper



Component

English

※ Optional replacement heads (two-row, angled, regular) sold separately



Handle

Wireless charging cradle

Replacement brush head storage case

User manual

1

Product structure

English



Toothbrush head

Power/Action button

Mode indicator LED


Charging indicator LED

Wireless charging cradle


2

Product function

English



Replacing the Brush Head



- **Installation:** Install the brush head as shown in the illustration on the left. Ensure the bristles are facing forward. Do not use excessive force if it is not aligned correctly, as this may damage the product.
- **Included Items:** Replacement brush heads are included in the package.
- **Replacement Interval:** We recommend replacing the brush head every 3 months. Replace it sooner if the bristles become worn or deformed. (Additional brush heads are sold separately.)
- **Compatibility:** This device is only compatible with genuine brush heads designed for this model. Using incompatible third-party heads may cause the device to malfunction.
- **1mm Gap:** A gap of approximately 1mm between the handle and the brush head is normal and required for proper vibration. Do not attempt to close this gap by pressing too hard, as it may cause damage to the device.


3

How to use

English

- 1. Preparation**
Apply an appropriate amount of toothpaste to the bristles. To prevent splashing, the intensity increases gradually over the first 3 seconds. Start brushing within this 3-second window.
- 2. Power ON & Intensity Control**
Press the power button briefly to turn the device on. While on, press the button again briefly to cycle through intensity levels. Select the intensity that suits you best.
- 3. Brushing & Power OFF**
A 2-minute brushing session is recommended. The device will automatically turn off after 2 minutes. To turn off the power manually during use, press and hold the power button for more than 1 second.
- 4. Cleaning & Storage**
After use, rinse the bristles thoroughly under running water and let them air dry. Store the device in a cool, dry place.

Smart 2-Minute Timer · 30-Second Interval Alert



- This product features a built-in timer to guide your brushing time.
- The session lasts for 2 minutes, after which the power shuts off automatically.
- To ensure even cleaning, the mouth is divided into 4 quadrants. Every 30 seconds, the device will pause briefly to signal you. Move to the next quadrant whenever you feel this vibration/pause.

4



- bright Implant Care에는 Gum · Daily · Intensive 세가지 모드가 있습니다. 사용자에게 맞는 모드를 설정 하여 사용하십시오.
- 모드 설정은 제품 전원이 ON인 상태에서 전원 버튼을 짧게 누르십시오. Gum → Daily → Intensive 순으로 반복하며 변경됩니다.
- bright Implant Care에는 메모리 기능이 있습니다. 사용자가 마지막으로 사용한 모드를 기억하고 다음 사용 시 해당 모드로 양치질을 시작합니다.

전원버튼

Intensive

Daily

Gum

칫솔 세척 및 보관



- 사용 후 즉시 칫솔 헤드는 흐르는 물에 깨끗하게 세척하고 건조하여 주십시오.
- 칫솔에 치약이 남아있거나 건조가 제대로 되지 않으면 세균번식의 원인이 될 수 있습니다.
- 세척 및 건조가 끝난 후에는 건조하고, 서늘한 곳에 보관 하여 주십시오.



- 사용 후 칫솔 본체는 물 또는 젖은 수건으로 가볍게 세척하여 주십시오.
- 세척 후에는 마른 수건으로 닦아 자연 건조하여 주십시오.
- 제품에 배터리가 내장되어 있으니 고온 다습한 환경에서 보관하지 마십시오.

Mode Settings



- bright Implant Care features three modes: Gum, Daily, and Intensive. Choose the mode that best suits your needs.
- To switch modes, briefly press the power button while the device is ON.The modes will cycle in the following order: Gum → Daily → Intensive.
- Memory Function:The device remembers your last used mode and will automatically start with that mode during your next session.

Power/Mode Button

Intensive

Daily

Gum

Cleaning & Storage



- Rinse the brush head thoroughly under running water immediately after use and allow it to dry.
- Residual toothpaste or improper drying can lead to bacterial growth.
- Once cleaned and dried, store the brush head in a cool, dry place.



- Lightly clean the handle with water or a damp cloth after use.
- Wipe with a dry towel and allow it to air dry.
- As this product contains a built-in battery, do not store it in hot or humid environments.



- 완충 시 최대 50일 사용 가능합니다. (강도별로 강: 30일, 중: 40일, 약: 50일/ 하루 세 번 2분씩 양치질 기준) 사용시간은 사용량에 따라 달라질 수 있습니다.
- 본 제품은 무선충전을 지원 합니다. 본체를 전원이 연결된 거치대에 가볍게 올려놓으면 충전이 시작됩니다.
- 충전 중 배터리 잔량 80%이하일 경우 적색, 그 이상이면 청색이 켜집니다. 사용 중 배터리 잔량이 20%이하일 경우 적색, 그 이상이면 청색이 켜집니다.
- 안전을 위해 충전 거치대와 가까워 지면 동작 되지 않습니다.
- 본 제품의 충전 규격은 5V 1A 입니다. 알맞은 규격의 어댑터를 사용하여 주십시오.(5V 1A 이하의 어댑터에서는 충전이 안될수 있습니다.
- USB 전원을 연결할 때 물기가 없도록 하십시오. 화재 및 감전의 원인이 될 수 있습니다.

A/S 및 유지 보수

A/S

본 제품은 6개월간 무상 A/S를 지원합니다. 6개월이 지난 후에는 유상으로 전환됩니다. 판매원 또는 제조사에 A/S를 문의하여 주십시오. (단, 무상 A/S 기간에도 사용자의 과실로 인한 사유라면 유상 A/S로 전환됩니다.)

폐기

본 제품에는 배터리 및 전자부품이 내장되어 있습니다. 배터리 및 전자제품을 지정된 장소에 폐기하지 않으면 환경오염의 원인이 될 수 있으므로 지정된 수거함에 폐기하여 주십시오.

주의사항

사용자 주의사항

- 사용방법 및 주의사항을 충분히 숙지 한 뒤 사용하십시오.
- 최근 잇몸 수술을 받았거나 잇몸이 심하게 부어있는 경우에는 전문의와 상의 후 사용하여 주십시오.
- 칫솔 사용 후 잇몸이 심하게 아프거나 구강 내 불편함이 생길 경우 사용을 즉시 중단하고 전문의와 상의 하십시오.
- 어린이가 가지고 놀지 못하게 하십시오. 전자기기 사용이 용이하지 않은 성인이나 13세 미만 어린이가 사용할 경우에는 보호자와 함께 사용하여 주십시오.
- 3세 미만의 어린이의 손이 닿지 않는 곳에 보관하여 주십시오.
- 칫솔을 너무 세게 밀어 사용하지 마십시오. 잇몸과 치아에 손상을 줄 수 있고 제품 고장의 원인이 될 수 있습니다.

충전 시 주의사항

- 제품 본체 하단에 위치한 충전 LED에 적색이 깜빡거리면 충전을 해주십시오.
- 본 제품에는 배터리가 내장되어 있습니다. 높은 온도나 심한 충격을 가하면 배터리 화재 및 폭발의 원인이 될 수 있습니다.
- 제품 규격에 맞는 어댑터를 사용해 주십시오. 규격에 맞지 않는 어댑터 사용은 제품 고장의 원인이 될 수 있습니다.(제품의 정격 입력은 5V / 1A / 5W 입니다.)
- 충전기를 욕조, 세면대 등 물기가 있는 곳에서 사용하지 마시고, 충전 시 USB단자에 물기가 있는지 확인해 주십시오. 충전기에 물기가 달으면 제품 고장 및 화재의 원인이 될 수 있습니다.

세척 및 유지보수 시 주의사항

- 칫솔모 교체 시 동봉 또는 별매로 판매되는 전용 칫솔모를 사용하여 주십시오. 다른 칫솔모는 호환 되지 않습니다.
- 칫솔 사용 후에는 칫솔모를 세척한 뒤 자연 건조하여 주십시오. 치약이 남아있거나 제대로 건조되지 않으면 세균이 번식할 수 있습니다.
- 사용한지 3달이 경과 되거나 칫솔모가 심하게 변형된 경우에는 칫솔모를 교체하여 주십시오.
- 칫솔모 및 칫솔 본체를 소독하기 위해 끓는 물,세제 또는 화학약품에 담그지 마십시오. 제품 고장의 원인이 될 수 있습니다.
- 제품을 사용하지 않을 경우에는 건조하고 안전한 곳에 보관하여 주십시오. 고온 다습한 환경은 제품 고장의 원인이 될 수 있습니다.

FAQ

진동 세기가 너무 약해요.

→ 칫솔을 세게 눌러 양치질을 한다면 진동이 약해질 수 있습니다. 칫솔을 세게 누르지 마시고, 약하게 접촉하여 사용하여 주십시오.

→ 칫솔 헤드를 너무 강하게 정척하면 내부 모터가 망가질 수 있습니다. 칫솔 헤드와 칫솔 본체 사이에 1mm정도의 틈이 있는지 확인하여 주십시오. 없다면 A/S를 요청하십시오.

충전을 해도 작동이 안돼요.

→ 출하 시 배터리가 방전되었거나, 전원 ON/OFF 사용 미숙일 수 있습니다. 설명서를 숙지하고 충전 후 사용하십시오. 그래도 작동하지 않는다면 A/S를 요청하십시오.

→ 배터리 수명이 다 되었을 수 있습니다. 완충을 시키고 사용하여 주십시오. 충전이 안되거나 완충 시에도 작동이 안된다면 A/S를 요청하십시오.

충전이 잘 안돼요.

→ USB 전원단자에 물, 먼지와 같은 이물질이 있다면 접촉 불량에 일어날 수 있습니다. USB 전원 단자를 깨끗하게 청소하고, 건조 후 사용 하십시오.

→ 무선 충전 거치대와 본체가 접촉하지 않을 수 있습니다. 무선 충전 거치대 속에 이물질이 있는지 확인하시고, 이물질 제거 후에도 충전이 안된다면 A/S를 요청하십시오.

진동이 너무 강해요 / 사용 후 잇몸이 아파요.

→ 펄스 잇몸이 약하다면 진동이 세게 느껴질 수 있습니다. 강도를 약으로 사용하시거나, 사용을 중단하고 전문의와 상의 후에 사용하십시오.

충전할 때 발열이 너무 심해요.

→ 무선충전 특성 상 발열이 어느정도 존재할 수 있습니다. 이상 발열이 발생하면 즉시 충전기의 전원을 차단하고 A/S를 요청하십시오.

작동할 때 이상한 소음이 나요.

→ 진동을 이용하는 제품으로, 일정량의 소음이 존재합니다. 이상 소음이 계속 발생한다면 A/S를 요청하십시오.

완충된 칫솔을 계속 충전기에 세워 두어도 괜찮을까요?

→ 본 제품에는 과충전 방지회로가 탑재되어 완충 후에는 충전이 종료됩니다. 배터리의 수명을 위하여 가급적 완충 후 충전기와 분리하는 것을 추천 드립니다.

충전기와 칫솔을 습한 화장실에 두어도 괜찮을까요?

→ 칫솔은 IPX8 방수를 지원하여 괜찮습니다. 하지만 충전기는 방수를 지원하지 않음으로 권장하지 않습니다. 세균 번식 및 곰팡이 방지를 위해 서늘하고 건조한 곳에 보관하는 것을 권장 드립니다.

칫솔 본체를 흐르는 물에 씻어도 괜찮을까요?

→ 본 제품은 IPX8 등급의 방수를 지원하므로 가능합니다. 충전기는 방수가 지원되지 않으므로 물 세척을 금합니다.

제품정보

상품명: bright Implant Care

모델명: BSET-001, BSET-002, BSET-003, BSET-004, BSET-005, BSET-006, SIP-WC-1.5

재질: ABS, PC, POM 외

정격입력: DC 5V, 1A

소비전력: 2W

모터 진동수: 21,000/ 분

무선충전 주파수: 100Khz ± 10%

배터리 사양: 3.7V, 1100mAh

방수 등급: IPX8

크기: 180 X 28.5 X 27.5 mm(본체)

무게: 116g

제조사 정보

제조원 : 제노스(대한민국)

경기도 수원시 영통구 청룡대로256번길 56, D-factory

Tel. 031-888-5100 www.genoss.com

A/S 및 제품 문의

무상 A/S 기간은 6개월이며 무상 A/S 기간이더라도 소비자 과실로 인한 수리 사유 시에는 유상으로 전환됩니다.

Tel. 031-888-5100 Fax. 031-8019-9123

Charging



- **Battery Life:** Lasts up to 50 days on a full charge.(Based on brushing twice daily for 2 minutes: 30 days on High, 40 days on Medium, 50 days on Low)Battery life may vary depending on usage.
- **Wireless Charging:** Supports wireless charging. Place the handle on the powered charging base to begin charging.
- **Charging Indicator:** Red light (below 80%), blue light (80% or above).
- **Usage Indicator:** Red light (below 20%), blue light (20% or above).
- **Safety Feature:** The device will not operate when placed on or near the charging base.
- **Power Specifications:** Rated at 5V 1A. Use a compatible adapter.(Charging may not work with adapters below 5V 1A.)
- **Warning:** Ensure the USB power connection is dry. Moisture may cause fire or electric shock.

Maintenance & Support

Warranty (A/S)

This product includes a 6-month limited warranty. After 6 months, repair services will be subject to a fee.

For service inquiries, please contact the seller or manufacturer.

Note: Damage caused by user misuse or negligence is not covered under the warranty.

Disposal

This product contains a built-in battery and electronic components. Do not dispose of with household waste. Please dispose of it at a designated electronic waste collection point to help protect the environment.

Precautions

User Safety

- Read all instructions carefully before use.
- Consult a dentist if you have recently undergone gum surgery or have severe gum swelling.
- Stop use and consult a doctor if you experience severe pain or discomfort.
- Keep out of reach of children under 3 years of age. Children under 13 or individuals requiring assistance should use this product under supervision.
- Do not apply excessive pressure, as it may damage teeth or gums or cause product malfunction.

Charging Safety

- Charge the device when the red LED indicator at the bottom flashes.
- This product contains a built-in battery. Avoid exposure to high temperatures or strong impacts to reduce the risk of fire or explosion.
- Use a compatible 5V/1A (5W) adapter. Using incompatible chargers may cause malfunction.
- Do not use the charger near water (e.g., bathtubs or sinks). Ensure the USB port is completely dry before charging to prevent fire or electric shock.

Maintenance Precautions

- Use only genuine replacement brush heads. Other types are not compatible.
- Rinse the brush head thoroughly after use and allow it to air dry to prevent bacterial growth.
- Replace the brush head every 3 months or sooner if the bristles become deformed.
- Do not immerse the handle or brush head in boiling water, detergents, or chemicals.
- Store the product in a cool, dry place. Exposure to extreme heat or humidity may cause damage.

Warranty (A/S)

This product includes a 6-month limited warranty. After 6 months, repair services will be subject to a fee.

For service inquiries, please contact the seller or manufacturer.

Note: Damage caused by user misuse or negligence is not covered under the warranty.

Disposal

This product contains a built-in battery and electronic components. Do not dispose of with household waste. Please dispose of it at a designated electronic waste collection point to help protect the environment.

FAQ

Q. The vibration is too weak.

→ Applying excessive pressure can reduce vibration. Use gentle pressure.

→ Attaching the brush head too tightly may affect motor performance. Ensure there is a 1 mm gap between the head and handle. If there is no gap and the vibration remains weak, contact Customer Service.

Q. It doesn't work even after charging.

→ The battery may be completely discharged, or the power button may not have been pressed correctly. Fully charge the device and try again.

→ The battery may have reached the end of its lifespan. If the device does not charge or operate after a full charge, contact Customer Service.

Q. The vibration is too strong / My gums hurt after use.

→ If you have sensitive gums, the vibration may feel strong. Use a lower intensity mode, or discontinue use and consult a dentist.

Q. It gets very hot during charging.

→ Wireless charging may generate some heat. However, if the device becomes excessively hot, disconnect the charger immediately and contact Customer Service.

Q. It makes a strange noise during operation.

→ Some noise is normal for motorized devices. If you hear continuous or unusual noise, contact Customer Service.

Q. Can I leave the fully charged handle on the charger?

→ The device includes overcharge protection. However, to extend battery life, we recommend removing it from the charger once fully charged.

Q. Can I keep the charger and handle in a humid bathroom?

→ The handle is rated IPX8 and is waterproof. However, the charger is not waterproof. Store both in a cool, dry place to prevent moisture buildup.

Q. Can I wash the handle under running water?

→ Yes, the handle is rated IPX8 and can be rinsed under running water. However, do not wash the charger, as it is not waterproof.

Product Specifications

Product Name: bright Implant Care

Models: BSET-001, BSET-002, BSET-003, BSET-004, BSET-005, BSET-006, SIP-WC-1.5

Materials: ABS, PC, POM, etc.

Rated Input: DC 5V, 1A

Power Consumption: 2 W

Motor Vibration: 21,000 vpm (vibrations per minute)

Wireless Charging Frequency: 100 kHz ± 10%

Battery Specifications: 3.7 V, 1100 mAh

Waterproof Rating: IPX8

Dimensions: 180 × 28.5 × 27.5 mm (handle)

Weight: 116 g

Manufacturer information

Manufacturer: GENOSS Co., Ltd. (South Korea)

D-factory, 56, Changnyong-daero 256beon-gil, Yeongtong-gu, Suwon-si, Gyeonggi-do, Republic of Korea

Tel: +82-31-888-5100 | Web: www.genoss.com

Customer Service & Inquiries

This product includes a 6-month limited warranty. Repairs after this period, or damage caused by user misuse or negligence (even within the warranty period), will be subject to a fee.

Tel. +82-31-888-5100 | Fax. +82-31-8019-9123